


## Hilti HIT-HY 200 mortar with HIS-(R)N sleeve

Injection mortar system	Benefits
	Hilti HIT-HY 200-A 500 ml foil pack (also available as 330 ml)
	Hilti HIT-HY 200-R 500 ml foil pack (also available as 330 ml)
	Static mixer
	Internal threaded sleeve HIS-N HIS-RN
	<ul style="list-style-type: none"> <li>- SAFEset technology: drilling and borehole cleaning in one step with Hilti hollow drill bit</li> <li>- Suitable for cracked and non-cracked concrete C 20/25 to C 50/60.</li> <li>- ETA seismic approval C1</li> <li>- High loading capacity, excellent handling, and fast curing</li> <li>- Small edge distance and anchor spacing possible</li> <li>- Corrosion resistant</li> <li>- In service temperature range up to 120°C short term/72°C long term</li> <li>- Manual cleaning for anchor size M8 and M10</li> <li>- Two mortar (A and R) versions available with different curing times and same performance</li> </ul>

					<b>SAFEset</b>			
Concrete	Tensile zone	Small edge distance and spacing	Corrosion resistance	Approved automatic cleaning while drilling	Hilti SAFEset technology with hollow drill bit	European Technical Approval	CE conformity	PROFIS Anchor design software

### Approvals / certificates

Description	Authority / Laboratory	No. / date of issue
European technical approval <sup>a)</sup>	DIBt, Berlin	ETA-11/0493 / 2013-06-20 (Hilti HIT-HY 200-A) ETA-12/0084 / 2013-06-08 (Hilti HIT-HY 200-R)

a) All data given in this section according ETA-11/0493 and ETA-12/0084, issue 2013-06-20.

## Basic loading data (for a single anchor)

All data in this section applies to

- Correct setting (See setting instruction)
- No edge distance and spacing influence
- Steel failure
- Base material thickness, as specified in the table
- One anchor material, as specified in the tables
- Concrete C 20/25,  $f_{ck,cube} = 25 \text{ N/mm}^2$
- Temperate range I  
(min. base material temperature -40°C, max. long term/short term base material temperature: +24°C/40°C)
- Installation temperature range -10°C to +40°C

For details see Simplified design method

**Embedment depth and base material thickness for the basic loading data. Mean ultimate resistance, characteristic resistance, design resistance, recommended loads.**

Anchor size	M8x90	M10x110	M12x125	M16x170	M20x205
Embedment depth $h_{ef}$ [mm]	90	110	125	170	205
Base material thickness $h$ [mm]	120	150	170	230	270

**Mean ultimate resistance: concrete C 20/25 , anchor HIS-N with screw 8.8**

Anchor size	M8x90	M10x110	M12x125	M16x170	M20x205
Non cracked concrete					
Tensile $N_{Ru,m}$ HIS-N [kN]	26,3	48,3	70,4	123,9	114,5
Shear $V_{Ru,m}$ HIS-N [kN]	13,7	24,2	41,0	62,0	57,8
Cracked concrete					
Tensile $N_{Ru,m}$ HIS-N [kN]	26,3	48,3	66,8	105,9	114,5
Shear $V_{Ru,m}$ HIS-N [kN]	13,7	24,2	41,0	62,0	57,8

**Characteristic resistance: concrete C 20/25 , anchor HIS-N with screw 8.8**

Anchor size	M8x90	M10x110	M12x125	M16x170	M20x205
Non cracked concrete					
Tensile $N_{Rk}$ HIS-N [kN]	25,0	46,0	67,0	111,9	109,0
Shear $V_{Rk}$ HIS-N [kN]	13,0	23,0	39,0	59,0	55,0
Cracked concrete					
Tensile $N_{Rk}$ HIS-N [kN]	24,7	39,9	50,3	79,8	105,7
Shear $V_{Rk}$ HIS-N [kN]	13,0	23,0	39,0	59,0	55,0

**Design resistance: concrete C 20/25 , anchor HIS-N with screw 8.8**

Anchor size	M8x90	M10x110	M12x125	M16x170	M20x205
Cracked concrete					
Tensile $N_{Rd}$ HIS-N [kN]	17,5	30,7	44,7	74,6	74,1
Shear $V_{Rd}$ HIS-N [kN]	10,4	18,4	26,0	39,3	36,7
Non cracked concrete					
Tensile $N_{Rd}$ HIS-N [kN]	16,5	26,6	33,5	53,2	70,4
Shear $V_{Rd}$ HIS-N [kN]	10,4	18,4	26,0	39,3	36,7

**Recommended loads <sup>a)</sup>: concrete C 20/25 , anchor HIS-N with screw 8.8**

Anchor size		M8x90	M10x110	M12x125	M16x170	M20x205
Non cracked concrete						
Tensile $N_{rec}$	HIS-N	[kN]	12,5	27,9	31,9	53,3
Shear $V_{rec}$	HIS-N	[kN]	7,4	13,1	18,6	28,1
Cracked concrete						
Tensile $N_{rec}$	HIS-N	[kN]	11,8	19,0	24,0	38,0
Shear $V_{rec}$	HIS-N	[kN]	7,4	13,1	18,6	28,1
						26,2

a) With overall partial safety factor for action  $\gamma = 1,4$ . The partial safety factors for action depend on the type of loading and shall be taken from national regulations.

## Service temperature range

Hilti HIT-HY 200 injection mortar may be applied in the temperature ranges given below. An elevated base material temperature may lead to a reduction of the design bond resistance.

Temperature range	Base material temperature	Maximum long term base material temperature	Maximum short term base material temperature
Temperature range I	-40 °C to +40 °C	+24 °C	+40 °C
Temperature range II	-40 °C to +80 °C	+50 °C	+80 °C
Temperature range III	-40 °C to +120 °C	+72 °C	+120 °C

### Max short term base material temperature

Short-term elevated base material temperatures are those that occur over brief intervals, e.g. as a result of diurnal cycling.

### Max long term base material temperature

Long-term elevated base material temperatures are roughly constant over significant periods of time.

## Materials

### Mechanical properties of HIS-(R)N

Anchor size		M8x90	M10x110	M12x125	M16x170	M20x205
Nominal tensile strength $f_{uk}$	HIS-N [N/mm <sup>2</sup> ]	490	460	460	460	460
	Screw 8.8 [N/mm <sup>2</sup> ]	800	800	800	800	800
	HIS-RN [N/mm <sup>2</sup> ]	700	700	700	700	700
	Screw A4-70 [N/mm <sup>2</sup> ]	700	700	700	700	700
Yield strength $f_{yk}$	HIS-N [N/mm <sup>2</sup> ]	410	375	375	375	375
	Screw 8.8 [N/mm <sup>2</sup> ]	640	640	640	640	640
	HIS-RN [N/mm <sup>2</sup> ]	350	350	350	350	350
	Screw A4-70 [N/mm <sup>2</sup> ]	450	450	450	450	450
Stressed cross-section $A_s$	HIS-(R)N [mm <sup>2</sup> ]	51,5	108,0	169,1	256,1	237,6
	Screw [mm <sup>2</sup> ]	36,6	58	84,3	157	245
Moment of resistance W	HIS-(R)N [mm <sup>3</sup> ]	145	430	840	1595	1543
	Screw [mm <sup>3</sup> ]	31,2	62,3	109	277	541

## Material quality

Part	Material
Internal threaded sleeve <sup>a)</sup> HIS-N	C-steel 1.0718, Steel galvanized $\geq 5\mu\text{m}$
Internal threaded sleeve <sup>b)</sup> HIS-RN	Stainless steel 1.4401 and 1.4571

- a) related fastening screw: strength class 8.8, A5 > 8% Ductile  
steel galvanized  $\geq 5\mu\text{m}$
- b) related fastening screw: strength class 70, A5 > 8% Ductile  
stainless steel 1.4401; 1.4404; 1.4578; 1.4571; 1.4439; 1.4362

## Anchor dimensions



Anchor size	M8x90	M10x110	M12x125	M16x170	M20x205
Internal threaded sleeve HIS-N / HIS-RN					
Embedment depth $h_{\text{ef}}$ [mm]	90	110	125	170	205

## Setting

### Installation equipment

Anchor size	M8x90	M10x110	M12x125	M16x170	M20x205
Rotary hammer	TE 2 – TE 16			TE 40 – TE 70	
Other tools	compressed air gun or blow out pump, set of cleaning brushes, dispenser				


### Setting instruction

Bore hole drilling	
	Drill hole to the required embedment depth with an appropriately sized Hilti TE-CD or TE-YD hollow drill bit with Hilti vacuum attachment. This drilling method properly cleans the borehole and removes dust while drilling. After drilling is complete, proceed to the "injection preparation" step in the instructions for use.
	Drill Hole to the required embedment depth with a hammer drill set in rotation-hammer mode using an appropriately sized carbide drill bit.


**Bore hole cleaning** Just before setting an anchor, the bore hole must be free of dust and debris.

**a) Manual Cleaning (MC) non-cracked concrete only**


for bore hole diameters  $d_0 \leq 20\text{mm}$  and bore hole depth  $h_0 \leq 10\text{d}$



The Hilti manual pump may be used for blowing out bore holes up to diameters  $d_0 \leq 20\text{ mm}$  and embedment depths up to  $h_{ef} \leq 10\text{d}$ . Blow out at least 4 times from the back of the bore hole until return air stream is free of noticeable dust




Brush 4 times with the specified brush size by inserting the steel brush Hilti HIT-RB to the back of the hole (if needed with extension) in a twisting motion and removing it. The brush must produce natural resistance as it enters the bore hole -- if not the brush is too small and must be replaced with the proper brush diameter.




Blow out again with manual pump at least 4 times until return air stream is free of noticeable dust.

**b) Compressed air cleaning (CAC)**


for all bore hole diameters  $d_0$  and all bore hole depth  $h_0$



Blow 2 times from the back of the hole (if needed with nozzle extension) over the hole length with oil-free compressed air (min. 6 bar at 6 m<sup>3</sup>/h) until return air stream is free of noticeable dust.




Brush 2 times with the specified brush size by inserting the steel brush Hilti HIT-RB to the back of the hole (if needed with extension) in a twisting motion and removing it. The brush must produce natural resistance as it enters the bore hole -- if not the brush is too small and must be replaced with the proper brush diameter.




Blow again with compressed air 2 times until return air stream is free of noticeable dust.

### Injection preparation



Tightly attach new Hilti mixing nozzle HIT-RE-M to foil pack manifold (snug fit). Do not modify the mixing nozzle. Observe the instruction for use of the dispenser. Check foil pack holder for proper function. Do not use damaged foil packs / holders. Swing foil pack holder with foil pack into HIT-dispenser.




Discard initial adhesive. The foil pack opens automatically as dispensing is initiated. Depending on the size of the foil pack an initial amount of adhesive has to be discarded.

Discard quantities are:


- 2 strokes for 330 ml foil pack,
- 3 strokes for 500 ml foil pack,
- 4 strokes for 500 ml foil pack  $\leq 5^{\circ}\text{C}$ .

### Inject adhesive


from the back of the borehole without forming air voids



Inject the adhesive starting at the back of the hole, slowly withdrawing the mixer with each trigger pull. Fill holes approximately 2/3 full, or as required to ensure that the annular gap between the anchor and the concrete is completely filled with adhesive along the embedment length.




After injection is completed, depressurize the dispenser by pressing the release trigger. This will prevent further adhesive discharge from the mixer.




Overhead installation and/or installation with embedment depth  $h_{\text{ef}} > 250\text{mm}$ . For overhead installation the injection is only possible with the aid of extensions and piston plugs. Assemble HIT-RE-M mixer, extension(s) and appropriately sized piston plug. Insert piston plug to back of the hole and inject adhesive. During injection the piston plug will be naturally extruded out of the bore hole by the adhesive pressure.


### Setting the element



Before use, verify that the element is dry and free of oil and other contaminants.  
Mark and set element to the required embedment depth until working time  $t_{\text{work}}$  has elapsed.



For overhead installation use piston plugs and fix embedded parts with e.g. wedges



Loading the anchor:  
After required curing time  $t_{\text{cure}}$  the anchor can be loaded.  
The applied installation torque shall not exceed  $T_{\text{max}}$ .


For detailed information on installation see instruction for use given with the package of the product.

## Working time, curing time


Temperature of the base material	Hilti HIT-HY 200-R	
	Working time in which anchor can be inserted and adjusted $t_{work}$	Curing time before anchor can be fully loaded $t_{cure}$
-10 °C to -5 °C	3 hour	20 hour
-4 °C to 0 °C	2 hour	8 hour
1 °C to 5 °C	1 hour	4 hour
6 °C to 10 °C	40 min	2,5 hour
11 °C to 20 °C	15 min	1,5 hour
21 °C to 30 °C	9 min	1 hour
31 °C to 40 °C	6 min	1 hour

Temperature of the base material	Hilti HIT-HY 200-A	
	Working time in which anchor can be inserted and adjusted $t_{work}$	Curing time before anchor can be fully loaded $t_{cure}$
-10 °C to -5 °C	1,5 hour	7 hour
-4 °C to 0 °C	50 min	4 hour
1 °C to 5 °C	25 min	2 hour
6 °C to 10 °C	15 min	75 min
11 °C to 20 °C	7 min	45 min
21 °C to 30 °C	4 min	30 min
31 °C to 40 °C	3 min	30 min

## Setting details



Anchor size	M8x90	M10x110	M12x125	M16x170	M20x205
Nominal diameter of drill bit $d_0$ [mm]	14	18	22	28	32
Diameter of element $d$ [mm]	12,5	16,5	20,5	25,4	27,6
Effective anchorage and drill hole depth $h_{\text{ef}}$ [mm]	90	110	125	170	205
Minimum base material thickness $h_{\min}$ [mm]	120	150	170	230	270
Diameter of clearance hole in the fixture $d_f$ [mm]	9	12	14	18	22
Thread engagement length; min - max $h_s$ [mm]	8-20	10-25	12-30	16-40	20-50
Torque moment <sup>a)</sup> $T_{\max}$ [Nm]	10	20	40	80	150
Minimum spacing $s_{\min}$ [mm]	40	45	55	65	90
Minimum edge distance $c_{\min}$ [mm]	40	45	55	65	90
Critical spacing for splitting failure $s_{\text{cr,sp}}$ [mm]	$2 c_{\text{cr,sp}}$				
Critical edge distance for splitting failure <sup>b)</sup> $c_{\text{cr,sp}}$ [mm]	$1,0 \cdot h_{\text{ef}}$ for $h / h_{\text{ef}} \geq 2,0$				
	$4,6 h_{\text{ef}} - 1,8 h$ for $2,0 > h / h_{\text{ef}} > 1,3$				
	$2,26 h_{\text{ef}}$ for $h / h_{\text{ef}} \leq 1,3$				
Critical spacing for concrete cone failure $s_{\text{cr,N}}$ [mm]	$2 c_{\text{cr,N}}$				
Critical edge distance for concrete cone failure <sup>c)</sup> $c_{\text{cr,N}}$ [mm]	$1,5 h_{\text{ef}}$				



For spacing (or edge distance) smaller than critical spacing (or critical edge distance) the design loads have to be reduced.

- a) Maximum recommended torque moment to avoid splitting failure during installation with minimum spacing and/or edge distance.
- b)  $h$ : base material thickness ( $h \geq h_{\min}$ ),  $h_{\text{ef}}$ : embedment depth
- c) The critical edge distance for concrete cone failure depends on the embedment depth  $h_{\text{ef}}$  and the design bond resistance. The simplified formula given in this table is on the safe side.

## Simplified design method

Simplified version of the design method according ETAG 001, TR 029. Design resistance according data given in ETA-11/0493 issued 2013-06-20 for HIT-HY 200-A and ETA-12/0084 issued 2013-06-20 for HIT-HY 200-R. Both mortars possess identical technical load performance.

- Influence of concrete strength
- Influence of edge distance
- Influence of spacing
- Valid for a group of two anchors. (The method may also be applied for anchor groups with more than two anchors or more than one edge distance. The influencing factors must then be considered for each edge distance and spacing. The simplified calculated design loads take a conservative approach: They will be lower than the exact values according to ETAG 001, TR 029. For an optimized design, anchor calculation can be performed using PROFIS anchor design software.)

The design method is based on the following simplification:

- No different loads are acting on individual anchors (no eccentricity)

The values are valid for one anchor.

For more complex fastening applications please use the anchor design software PROFIS Anchor.


## Tension loading

**The design tensile resistance is the lower value of**

- Steel resistance:  $N_{Rd,s}$
- Combined pull-out and concrete cone resistance:  

$$N_{Rd,p} = N_{Rd,c}^0 \cdot f_{B,p} \cdot f_{1,N} \cdot f_{2,N} \cdot f_{3,N} \cdot f_{h,p} \cdot f_{re,N}$$
- Concrete cone resistance:  $N_{Rd,c} = N_{Rd,c}^0 \cdot f_B \cdot f_{1,N} \cdot f_{2,N} \cdot f_{3,N} \cdot f_{h,N} \cdot f_{re,N}$
- Concrete splitting resistance (only non-cracked concrete):  

$$N_{Rd,sp} = N_{Rd,c}^0 \cdot f_B \cdot f_{1,sp} \cdot f_{2,sp} \cdot f_{3,sp} \cdot f_{h,N} \cdot f_{re,N}$$



## Basic design tensile resistance

### Design steel resistance $N_{Rd,s}$

Anchor size	M8x90	M10x110	M12x125	M16x170	M20x205
HIS-N with screw 8.8 [kN]	17,5	30,7	44,7	80,3	74,1
N <sub>Rd,s</sub> HIS-RN with screw A4-70 [kN]	13,9	21,9	31,6	58,8	69,2

### Design combined pull-out and concrete cone resistance

$$N_{Rd,p} = N_{Rd,p}^0 \cdot f_{B,p} \cdot f_{1,N} \cdot f_{2,N} \cdot f_{3,N} \cdot f_{h,p} \cdot f_{re,N}$$

Anchor size	M8x90	M10x110	M12x125	M16x170	M20x205
Embedment depth $h_{ef}$ [mm]	90	110	125	170	205
Non cracked concrete					
$N_{Rd,p}^0$ Temperature range I [kN]	30,6	49,4	69,8	117,6	154,7
$N_{Rd,p}^0$ Temperature range II [kN]	25,9	41,8	59,0	99,5	130,4
$N_{Rd,p}^0$ Temperature range III [kN]	22,4	36,1	51,0	85,9	112,6
Cracked concrete					
$N_{Rd,p}^0$ Temperature range I [kN]	16,5	26,6	37,6	63,3	83,0
$N_{Rd,p}^0$ Temperature range II [kN]	13,0	20,9	29,5	49,7	65,2
$N_{Rd,p}^0$ Temperature range III [kN]	11,8	19,0	26,8	45,2	59,3

$$\text{Design concrete cone resistance } N_{Rd,c} = N_{Rd,c}^0 \cdot f_B \cdot f_{1,N} \cdot f_{2,N} \cdot f_{3,N} \cdot f_{h,N} \cdot f_{re,N}$$

$$\text{Design splitting resistance } a) N_{Rd,sp} = N_{Rd,sp}^0 \cdot f_B \cdot f_{1,sp} \cdot f_{2,sp} \cdot f_{3,sp} \cdot f_{h,N} \cdot f_{re,N}$$

Anchor size	M8	M10	M12	M16	M20
Non cracked concrete					
$N_{Rd,c}^0$ [kN]	28,7	38,8	47,1	74,6	98,8
Cracked concrete					
$N_{Rd,c}^0$ [kN]	20,5	27,7	33,5	53,2	70,4

a) Splitting resistance must only be considered for non-cracked concrete.

### Influencing factors

#### Influence of concrete strength on combined pull-out and concrete cone resistance

Concrete strength designation (ENV 206)	C 20/25	C 25/30	C 30/37	C 35/45	C 40/50	C 45/55	C 50/60
$f_{B,p} = (f_{ck,cube}/25N/mm^2)^{0,10} a)$				$f_{B,p} = 1$			

a)  $f_{ck,cube}$  = concrete compressive strength, measured on cubes with 150 mm side length

#### Influence of embedment depth on combined pull-out and concrete cone resistance

$$f_{h,p} = 1$$

#### Influence of concrete strength on concrete cone resistance

Concrete strength designation (ENV 206)	C 20/25	C 25/30	C 30/37	C 35/45	C 40/50	C 45/55	C 50/60
$f_B = (f_{ck,cube}/25N/mm^2)^{0,5} a)$	1	1,1	1,22	1,34	1,41	1,48	1,55

a)  $f_{ck,cube}$  = concrete compressive strength, measured on cubes with 150 mm side length

#### Influence of edge distance <sup>a)</sup>

$c/c_{cr,N}$	0,1	0,2	0,3	0,4	0,5	0,6	0,7	0,8	0,9	1
$c/c_{cr,sp}$										
$f_{1,N} = 0,7 + 0,3 \cdot c/c_{cr,N} \leq 1$	0,73	0,76	0,79	0,82	0,85	0,88	0,91	0,94	0,97	1
$f_{1,sp} = 0,7 + 0,3 \cdot c/c_{cr,sp} \leq 1$										
$f_{2,N} = 0,5 \cdot (1 + c/c_{cr,N}) \leq 1$	0,55	0,60	0,65	0,70	0,75	0,80	0,85	0,90	0,95	1
$f_{2,sp} = 0,5 \cdot (1 + c/c_{cr,sp}) \leq 1$										

a) The edge distance shall not be smaller than the minimum edge distance  $c_{min}$ . These influencing factors must be considered for every edge distance smaller than the critical edge distance.

**Influence of anchor spacing <sup>a)</sup>**

$s/s_{cr,N}$	0,1	0,2	0,3	0,4	0,5	0,6	0,7	0,8	0,9	1
$s/s_{cr,sp}$										
$f_{3,N} = 0,5 \cdot (1 + s/s_{cr,N}) \leq 1$	0,55	0,60	0,65	0,70	0,75	0,80	0,85	0,90	0,95	1
$f_{3,sp} = 0,5 \cdot (1 + s/s_{cr,sp}) \leq 1$										

- a) The anchor spacing shall not be smaller than the minimum anchor spacing  $s_{min}$ . This influencing factor must be considered for every anchor spacing.

**Influence of embedment depth on concrete cone resistance**

$$f_{h,N} = 1$$

**Influence of reinforcement**


$h_{ef}$ [mm]	40	50	60	70	80	90	$\geq 100$
$f_{re,N} = 0,5 + h_{ef}/200\text{mm} \leq 1$	0,7 <sup>a)</sup>	0,75 <sup>a)</sup>	0,8 <sup>a)</sup>	0,85 <sup>a)</sup>	0,9 <sup>a)</sup>	0,95 <sup>a)</sup>	1

- a) This factor applies only for dense reinforcement. If in the area of anchorage there is reinforcement with a spacing  $\geq 150$  mm (any diameter) or with a diameter  $\leq 10$  mm and a spacing  $\geq 100$  mm, then a factor  $f_{re,N} = 1$  may be applied.

## Shear loading

**The design shear resistance is the lower value of**

- Steel resistance:  $V_{Rd,s}$
- Concrete prout resistance:  $V_{Rd,cp} = k \cdot \text{lower value of } N_{Rd,p} \text{ and } N_{Rd,c}$
- Concrete edge resistance:  $V_{Rd,c}^0 = V_{Rd,c}^0 \cdot f_B \cdot f_B \cdot f_h \cdot f_4 \cdot f_{hef} \cdot f_c$



## Basic design shear resistance

**Design steel resistance  $V_{Rd,s}$** 

Anchor size	M8x90	M10x110	M12x125	M16x170	M20x205
HIS-N with screw 8.8 [kN]	10,4	18,4	26,0	39,3	36,7
$V_{Rd,s}$ HIS-RN with screw A4-70 [kN]	8,3	12,8	19,2	35,3	41,5

**Design concrete prout resistance  $V_{Rd,cp} = \text{lower value}^a)$  of  $k \cdot N_{Rd,p}$  and  $k \cdot N_{Rd,c}$** 

$$k = 2$$

- a)  $N_{Rd,p}$ : Design combined pull-out and concrete cone resistance  
 $N_{Rd,c}$ : Design concrete cone resistance

**Design concrete edge resistance  $V_{Rd,c}$**   $= V_{Rd,c}^0 \cdot f_B \cdot f_B \cdot f_h \cdot f_4 \cdot f_{hef} \cdot f_c$

Anchor size	M8	M10	M12	M16	M20
Non-cracked concrete					
$V_{Rd,c}^0$	[kN]	12,4	19,6	28,2	40,2
Cracked concrete					
$V_{Rd,c}^0$	[kN]	8,8	13,9	20,0	28,5
					32,7

## Influencing factors

### Influence of concrete strength

Concrete strength designation (ENV 206)	C 20/25	C 25/30	C 30/37	C 35/45	C 40/50	C 45/55	C 50/60
$f_B = (f_{ck,cube}/25\text{ N/mm}^2)^{1/2}$ a)	1	1,1	1,22	1,34	1,41	1,48	1,55

a)  $f_{ck,cube}$  = concrete compressive strength, measured on cubes with 150 mm side length

### Influence of angle between load applied and the direction perpendicular to the free edge

Angle $\beta$	0°	10°	20°	30°	40°	50°	60°	70°	80°	≥ 90°
$f_\beta = \sqrt{\frac{1}{(\cos \alpha_v)^2 + \left(\frac{\sin \alpha_v}{2,5}\right)^2}}$	1	1,01	1,05	1,13	1,24	1,40	1,64	1,97	2,32	2,50

### Influence of base material thickness

h/c	0,15	0,3	0,45	0,6	0,75	0,9	1,05	1,2	1,35	≥ 1,5
$f_h = \{h/(1,5 \cdot c)\}^{1/2} \leq 1$	0,32	0,45	0,55	0,63	0,71	0,77	0,84	0,89	0,95	1,00

**Influence of anchor spacing and edge distance<sup>a)</sup> for concrete edge resistance:  $f_4$**   

$$f_4 = (c/h_{ef})^{1,5} \cdot (1 + s / [3 \cdot c]) \cdot 0,5$$

c/h <sub>ef</sub>	Single anchor	Group of two anchors s/h <sub>ef</sub>														
		0,75	1,50	2,25	3,00	3,75	4,50	5,25	6,00	6,75	7,50	8,25	9,00	9,75	10, 50	11, 25
0,50	0,35	0,27	0,35	0,35	0,35	0,35	0,35	0,35	0,35	0,35	0,35	0,35	0,35	0,35	0,35	0,35
0,75	0,65	0,43	0,54	0,65	0,65	0,65	0,65	0,65	0,65	0,65	0,65	0,65	0,65	0,65	0,65	0,65
1,00	1,00	0,63	0,75	0,88	1,00	1,00	1,00	1,00	1,00	1,00	1,00	1,00	1,00	1,00	1,00	1,00
1,25	1,40	0,84	0,98	1,12	1,26	1,40	1,40	1,40	1,40	1,40	1,40	1,40	1,40	1,40	1,40	1,40
1,50	1,84	1,07	1,22	1,38	1,53	1,68	1,84	1,84	1,84	1,84	1,84	1,84	1,84	1,84	1,84	1,84
1,75	2,32	1,32	1,49	1,65	1,82	1,98	2,15	2,32	2,32	2,32	2,32	2,32	2,32	2,32	2,32	2,32
2,00	2,83	1,59	1,77	1,94	2,12	2,30	2,47	2,65	2,83	2,83	2,83	2,83	2,83	2,83	2,83	2,83
2,25	3,38	1,88	2,06	2,25	2,44	2,63	2,81	3,00	3,19	3,38	3,38	3,38	3,38	3,38	3,38	3,38
2,50	3,95	2,17	2,37	2,57	2,77	2,96	3,16	3,36	3,56	3,76	3,95	3,95	3,95	3,95	3,95	3,95
2,75	4,56	2,49	2,69	2,90	3,11	3,32	3,52	3,73	3,94	4,15	4,35	4,56	4,56	4,56	4,56	4,56
3,00	5,20	2,81	3,03	3,25	3,46	3,68	3,90	4,11	4,33	4,55	4,76	4,98	5,20	5,20	5,20	5,20
3,25	5,86	3,15	3,38	3,61	3,83	4,06	4,28	4,51	4,73	4,96	5,18	5,41	5,63	5,86	5,86	5,86
3,50	6,55	3,51	3,74	3,98	4,21	4,44	4,68	4,91	5,14	5,38	5,61	5,85	6,08	6,31	6,55	6,55
3,75	7,26	3,87	4,12	4,36	4,60	4,84	5,08	5,33	5,57	5,81	6,05	6,29	6,54	6,78	7,02	7,26
4,00	8,00	4,25	4,50	4,75	5,00	5,25	5,50	5,75	6,00	6,25	6,50	6,75	7,00	7,25	7,50	7,75
4,25	8,76	4,64	4,90	5,15	5,41	5,67	5,93	6,18	6,44	6,70	6,96	7,22	7,47	7,73	7,99	8,25
4,50	9,55	5,04	5,30	5,57	5,83	6,10	6,36	6,63	6,89	7,16	7,42	7,69	7,95	8,22	8,49	8,75
4,75	10,35	5,45	5,72	5,99	6,27	6,54	6,81	7,08	7,36	7,63	7,90	8,17	8,45	8,72	8,99	9,26
5,00	11,18	5,87	6,15	6,43	6,71	6,99	7,27	7,55	7,83	8,11	8,39	8,66	8,94	9,22	9,50	9,78
5,25	12,03	6,30	6,59	6,87	7,16	7,45	7,73	8,02	8,31	8,59	8,88	9,17	9,45	9,74	10, 02	10, 31
5,50	12,90	6,74	7,04	7,33	7,62	7,92	8,21	8,50	8,79	9,09	9,38	9,67	9,97	10, 26	10, 55	10, 85

a) The anchor spacing and the edge distance shall not be smaller than the minimum anchor spacing  $s_{min}$  and the minimum edge distance  $c_{min}$ .

### Influence of embedment depth

Anchor size	M8	M10	M12	M16	M20
$f_{hef} =$	1,38	1,21	1,04	1,22	1,45

### Influence of edge distance<sup>a)</sup>

c/d	4	6	8	10	15	20	30	40
$f_c = (d / c)^{0,19}$	0,77	0,71	0,67	0,65	0,60	0,57	0,52	0,50

a) The edge distance shall not be smaller than the minimum edge distance  $c_{min}$ .

### Combined tension and shear loading

For combined tension and shear loading see section "Anchor Design".

